ADMIRATEY SIGNAL & RADAR ESTABLISHMENT

CV58

Indicate	ton a change										
	Indicates a change										
TYPE OF VALVE: - Diode of "axial" type for use down to 9 cms.	MARKING See K1001/4										
CATHODE: - Indirectly heated.	BASE										
PROTOTYPE:- E1273	Concentric fitting, consisting of cathode tube and filament pin, for use with co-axial line. Anode connection to pin										
<u>RATING</u> S	at other end of valve. See page 3.										
Heater Voltage (V) 6.3 A Meater Current (A) 0.36 Minimum Conductance (mA/V) 1.4 B	DIMENSIONS See Page 3.										

NOTES

- A. Within limits + 0.2, 0.4 V. The anode-cathode clearance varies with cathode temperature, and these limits should not be exceeded in operation or some fall in performance as a mixer will result.
- B. At Ia = 1 mA

TESTS


To be performed in addition to those applicable in K1001

			4.07	Insp.	Sambal	Limits		Units	
	Test		Level	Symbol	Min.	Max.			
a	Heater Current	V _h = 6.3V		100%	Ih	0.335	0.385	A	
ъ	Conductance	$V_h = 6.3V$ $I_a = 1.0 \text{ mA}$ Note 1		100%	gm	1.4	_	m a /V	
c	Capacitance	V _h = 6.3V Note 2	6.5	IB	C_{a-k+h}	-	2.5	hfr <u>E</u> g	←
đ	Leakage Conductance	V _h = 6.3V	6.5	IB	-	-	4	umhos	←

NOTES


- 1. To be measured with Va (D.C.) adjusted for 1.0 mA, and then varied + 0.1V.
- 2. The Heater Voltage supply to be D.C. Capacitance and Leakage Conductance are to be measured on a standard R.F. Capacitance Bridge, using a jig such as is shown on page 4.
- 3. The above tests are designed to enusre satisfactory operation at a wavelength of 10 cms.

CV.58/7/2



ALL DIMENSIONS IN MILLIMETRES

MOUNT FOR CV58 FOR PURPOSE
OF CAPACITANCE AND LEAKAGE
CONDUCTANCE MEASUREMENTS.
MATERIAL -BRASS.



NOTE. D.C. HEATER VOLTAGE TO BE APPLIED BY
CLIPPING FLEXIBLE LEADS ON TO POINTS XX.